

TRACE GAS MONITOR

GA-360E Series





The two-in-one high-sensitivity analyzer

- NDIR absorption method with unique crossflow modulation technique.
- ◆ Designed to measure impurities in bulk gas (N₂) used in semiconductor and other high-purity gases such as He, O₂, Air and Ar, used in clean rooms, medical facilities and manufacturing processes.
- Simultaneous and continuous measurement of any two components among CO, CO₂ and CH₄.
- Compact and lightweight, fits in a standard 19-inch rack.

HORIBA is a worldwide leader in non-dispersive infrared (NDIR) technology and a major NDIR analyzer manufacturer. The heart of the GA-360E Trace Gas Monitor is the multinationally accepted, field-proven, cross-flow modulated HORIBA NDIR analyzer.


Highly reliable trace gas monitors

The GA-360E represents a concept in trace gas monitors, is designed to eliminate routine calibration cycles and to provide long-term stable measurement and continuous unattended operation. It furnishes reliable concentration. Every element of the monitor has been selected to offer

the ultimate in reliability and accuracy. Solid-state modular electronics ensure optimum performance and minimum maintenance.


Available in one-or two-component versions

The GA-360E is available in a one-component version to measure a single component, or a two-component versions for measuring any combination of CO, $\rm CO_2$ and / or $\rm CH_4$ specified by the customer. Simultaneous measurement of two different components is made possible by linking two detectors to the main unit via a single sample line.



BPA-PSD: Brand Pass Amplitier Phase Sensitive Detection LPF: Low Pass Filter

An infrared beam in the analyzer unit passes through the cell to the detector. During measurement, the solenoid valves alternately direct the sample gas and the reference gas (supplied by the customer) to the cells of the analyzer. The presence of CO, CO₂ and/or CH₄ in the sample gas generates a difference in the intensity of the light reaching the detector when the cell is filled with sample gas from when it is filled with reference gas. This defference causes a metalic membrane in the detector to move back and forth in accordance with the alternating gas flow (cross-flow modulation). The analyzer requires neither an optical chopper nor optical adjustment. Furthermore. this technique virtually eliminates zero drift and greatly enhances analyzer sensitivity. Zero and span calibrations are performed by introducing standard gases.



SPECIFICATIONS

Model name: GA-360E

Principle: Non-dispersive infrared

(NDIR) absorption technolgy

Application: CO, CO₂ and CH₄ in N₂,

He, O₂, Air, and Ar. **Range:** 0 - 1/2/5/10 ppm

Min. detection sensitivity: 0.01 ppm

(1 sigma)

Repeatability: ±2% F.S. Linearity: ±2% F.S.

Zero drift: ±0.02 ppm/day

±0.03 ppm/7days

Span drift: ±2% F.S./day

±3% F.S./7days

Response time (T₉₀): Within 180 sec.

Sample gas flow rate:

Approx. 3.5L/min

Reference gas flow rate:

Approx. 3.5L/min

Indication: Measured value, range,

Reference gas: N₂, He, O₂, Air, and

Sample / Reference gas pressure:

50~100kpa


Alarm: Flow, chopper, power down Output: 0 - 1 V, 10V, 4 - 20 mA **Power :** AC 100 V, 110 V, 115 V, 220 V,


230 V, 240 V (to be specified)

Remarks:

- 1) The two-component version measures any two of the above three components specified by the customer.
- 2) Reference gas is to be supplied by the customer.

Dimensional Outlines Unit: mm (in)





http://www.horiba.com e-mail: info@horiba.co.jp

●HORIBA, Ltd. **Head Office**

2 Miyanohigashi, Kisshoin Minami-ku, Kyoto, Japan Phone: 81 (75) 313-8123 Fax: 81 (75) 321-5725

●HORIBA INSTRUMENTS

Pte. LTD.

10 Ubi Crescent

#05-11/12, Ubi Techpark

Singapore 408564 Phone: 65 6745-8

●HORIBA GmbH

Kaplanstrasse 5 A-3430 Tulin, Austria

Phone: 65 6745-8300 Fax: 65 6745-8155

Tokyo Sales Office 1-7-8 Higashi-Kanda Chiyoda-ku, Tokyo, Japar Phone: 81 (3) 3861-8231 Fax: 81 (3) 3861-8259

HORIBA India Private Limited Delhi Office Pu 1212A, Hemkunt Tower, 50

98 Nehru Place, New Delhi - 110019 INDIA Phone: +91 11-4669-5001/5002

HORIBA CZECHIA Organizachi slozka Praha Petrohradska 13 CZ-101_00 Praha 10,

Czech Republic Phone: 420 (2) 717-464-80 Fax: 420 (2) 717-470-64

Pune Office 502, Purushottam Plaza, Baner Road, Baner

Fax: 21-6289-5553

Pune - 411045 INDIA Phone: +91 20-2729-1121

●HORIBA FUROPE GmbH Head Office Hans-Mess-Str.6 D-61440 Oberursel/Ts.

Germany Phone: 49 (6172) 1396-0 Fax: 49 (6172) 137385

 HORIBA TRADING (SHANGHAI) CO., Ltd.
Shanghai Office
Room 1701, United Plaza,
1468 Nanjing Rd. West,
Shanghai, 200040, China
Phone: 21-6289-6060
Phone: 21-6289-6060
Room 1801, Capital Tower Beijing,
Tower 1 No.6Jia, Jianguomenwai Ave.,
Chaoyang District, Beijing,
100022 China
Room 1801, Capital Tower Beijing,
100022 China Phone: 10-8567-9966 Fax: 10-8567-9066

● HORIBA INSTRUMENTS INCORPORATED Irvine Facility

17671 Armstrong Avenue Irvine, CA 92614, U.S.A. Phone: 1 (949) 250-4811 Fax: 1 (949) 250-0924

Leichlingen Facility Julius-kronenberg Strasse D-42799 Leichlingen Germany Phone: 49 (2175) 8978-0

Fax: 49 (2175) 8978-50

●HORIBA KOREA Ltd.

112-6 Sogong-Dong Choong-ku, Seoul, Korea Phone: 82 (2) 753-7911 Fax: 82 (2) 756-4972

● HORIBA INSTRUMENTS

Kyoto Close Summerhouse Road Moulton Park, Northampton NN3 6FL, U.K. Phone: 44 (1604) 542500 Fax: 44 (1604) 542699

●HORIBA FRANCE

12, Avenue des Tropiques 91955 LES ULIS

Phone: 33 (1) 69-29-96-23 Fax: 33 (1) 69-29-95-77

Bulletin:HRE-2844D

Explore the future

Fax: 43 (2272) 65230

Phone: 43 (2272) 65225

Printed in Japan T-Y(SK)23